

Processing Notes

General

We recommend pigment colors for overdipping.

Dyes are generally used for candles that are colored throughout. Depending on the shade, production method and type of candle, however, pigment colorants and pigment-dye combinations may also be used.

Application

1. Use an electronic scale to weigh out the exact quantity of colorant.
2. Dissolve the colorant in wax at a ratio of about 1:10.
The wax temperature at this ratio should be around 90° C.
3. Mix thoroughly using an electric mixer or compressed air mixer until the color is completely melted into the wax.
4. Pour the color-wax melt into the wax tank and mix it again using a mixer. This applies especially to pigment colorants.
5. Check that the color is correct before starting candle production.

